

14
*
74

Push Button Switch



SHORT

T-TOP-C7x7-A ON-ON
T-TOP-C7x7-B ON-(ON)